


WITHOUT DAMAGING ADJACENT SOUND BRICKS.

- 3. VERIFY THAT SUBSTRATE IS IN GOOD CONDITION. REPAIR AS REQUIRED.
- 4. PARGE INTERIOR BLOCK WYTHE WITH MORTAR.
- 5. REPLACE DAMAGED FLASHING WITH NEW FLASHING AND PLASTIC CEMENT WHERE
- 6. PRE-WET BOTH NEW AND SURROUNDING BRICKS BEFORE LAYING, BUT THEY SHALL NOT BE WET AT THE TIME OF LAYING. THOROUGHLY WET THE ABUTTING BRICK
- 7. THE NEW BRICKWORK TO THE BACK-UP WALLS AND COLUMNS WITH BRICK TIES AND ANCHORS, AND TOOTH INTO THE EXISTING BRICKWORK. REPLACE EXISTING WEEPHOLES WITH NEW WEEPHOLES WHERE APPLICABLE.
- 8. KEEP CAVITIES FREE OF MORTAR DROPPINGS.

BRICK MASONRY REPLACEMENT AT CAVITY WALL SCALE: N.T.S.

PROVIDE TEMPORARY SHORING AS REQUIRED. CONTRACTOR TO PROVIDE TEMPORARY SHORING DRAWINGS AND CALCULATIONS SIGNED AND SEALED BY A PROFESSIONAL ENGINEER LICENSED IN THE STATE OF NY FOR REVIEW.



BRICK REPLACEMENT

A.C.

S-003.00